







Adaptador 3 Tomas EUR
Ficha Tripla EUR








Ref. 61045

Ref. 61055

 1	 3	2200 W 10A/250V~		Ref. 61045 
		 1	 12	Ref. 61055 






Adaptador Doble EUR P/Toma Schuko
Adaptador Duplo Europeu P/Tomada Schuko



 1	 2	3500 W 16A/250V~			
		 1	 12	Ref. 61215 	







Adaptador Triple EUR P/Toma Schuko
Adaptador Triplo Europeu P/Tomada Schuko








 1	 3	3500 W 16A/250V~			
		 1	 12	Ref. 61245 	

Adaptador Mixto (1 Schuko + 2 EUR)
Adaptador Mixto (1 Schuko + 2 EUR)








 1	 1	 2	3500 W 16A/250V~		
		 1	 12	Ref. 61315 	

Adaptador Doble Schuko
 Adaptador Duplo Schuko

 1	 2	3500 W 16A/250V~			
	 1	 12	Ref. 61415		8 436038 001818









Adaptador 2 Tomas Schuko Frontal
 Adaptador Schuko Frontal

 1	 2	3500 W 16A/250V~			
	 1	 12	Ref. 61445		8 436038 001825








Adaptador Triple Schuko
 Adaptador Triplo Schuko

 1	 3	3500 W 16A/250V~			
	 1	 12	Ref. 61515		8 436038 001832



Adaptador 3 Tomas Schuko Frontal
 Adaptador Schuko Frontal

 1	 3	3500 W 16A/250V~			
	 1	 12	Ref. 61575		8 436038 001856



Adaptador de Viaje
Adaptador de Viagem



2200 W
10A/250V~



Ref. 61805



8 436038 001863



Adaptador Múltiple de Viaje
Adaptador Multiplo de Viagem



1650 W
7,5A/250V~



Ref. 61855



8 436038 001870



Adaptador Doble Schuko
Adaptador Duplo Schuko



3500 W
16A/250V~



Ref. 61925



8 436038 001887

